8BitDo®


Instruction Manual


8BitDo Retro Cube 2 Speaker ---------- 01


8BitDo®

8BitDo Retro Cube 2 Speaker

English







* Press the **Power button** to turn on the speaker.
* Press the **Power button** to turn off the speaker.
* Press and hold the **Power button** for 8 seconds to restore the speaker to factory settings.

1 — USB-C port

2 — 2.4G adapter/Adapter compartment

3 — Mode switch

4 — Audio mode switch (Music mode/Game mode)

5 — Power button - Power on/Power off

6 — Volume +

7 — Volume -

8 — Play button - Single press: Play/Pause. Double press: Next track. Triple press: Previous track. Press and hold it for 3 seconds in Bluetooth mode to enter pairing mode. Answer/End call (available in Bluetooth mode only).

9 — Microphone

Bluetooth Connection

1. Turn the **Mode switch** to **BT** position.
2. Press the **Power button** to turn on the speaker.
3. Press and hold the **Play button** for 3 seconds to enter its pairing mode, the **Blue Status LED** will blink rapidly. (This is required for the very first time only)
4. Go to your device's "Bluetooth Setting" and turn it on, pair with **"8BitDo Cube 2"** , the **Blue Status LED** will remain solid to indicate a successful connection.

Wireless Connection

1. Connect the **2.4G adapter** to your device's **USB** port.

2. Turn the **Mode switch** to **2.4G** position.
3. Press the **Power button** to turn on the speaker, the **White Status LED** will remain solid to indicate a successful connection.

Wired Connection

Connect the speaker to your device via a USB cable, the device is ready to use after connection is complete.

Battery

Built-in 2000mAh battery pack, 30 hours of usage time, rechargeable with 3-5 hours charging time.

Status-		Power LED-
Low battery	⟶	Red LED blinks
Battery charging	⟶	Red LED stays solid
Fully charged	⟶	Red LED turns off

* The speaker will automatically shut down if it fails to connect within 1 minute of startup, or if there are no operations within 15 minutes after establishing a connection.
* The speaker will not shut down during wired connection.
* Charging and battery life depend on variations in settings or environmental factors, and actual results may vary.

Safety Warnings

* Please always use batteries, chargers, and accessories provided by the manufacturer.
* The manufacturer is not liable for any safety issues arising from the use of non-manufacturer-approved accessories.
* Do not attempt to disassemble, modify, or repair the device yourself. Unauthorized actions may result in serious injury.
* Avoid crushing, disassembling, puncturing, or attempting to modify the device or its battery, as these actions can be dangerous.
* Any unauthorized changes or modifications to the device will void the manufacturer's warranty.
* This product contains small parts that may cause choking. Not suitable for children under three years old.
* This product features flashing lights. Individuals with epilepsy or photosensitivity should disable the lighting effects before use.
* Cables may cause tripping or entanglement hazards. Keep them away from walkways, children, and pets.
* Stop using this product immediately and seek medical attention if you experience dizziness, visual disturbances, or muscle spasms.
* Avoid contact between the charging dock surface and other devices or foreign objects.

Firmware Update

Please visit app.8bitdo.com to download **Ultimate Software V2** for Windows / macOS.

Support

Please visit support.8bitdo.com for further information & additional support.



Manual

