
8BitDo

Ultimate 2C Bluetooth Controller

English



- Press the **Home button** to turn on the controller.
- Hold the **Home button** for 3 seconds to turn off the controller.
- Hold the **Home button** for 8 seconds to force the controller off.

Switch

- System requirements: Switch 3.0.0 or above.
- NFC scanning, IR camera, HD rumble, and notification LED are not supported.

Bluetooth Connection

1. Press the **Home button** to turn on the controller.
2. Hold the **Pair button** for 3 seconds to enter its pairing mode, and the **Status LED** will start to blink rapidly (This is required for the very first time only).
3. Go to Switch's Controller > Change Grip/Order, and wait for the connection.
4. The **Status LED** will remain solid to indicate a successful connection.

Wired Connection

- Ensure the **System Setting** > **Controllers and Sensors** > **Pro Controller Wired Communication** is turned on.
- Connect the controller to the USB port of your Switch and wait till the controller is successfully recognized by your Switch to play.

Turbo Function

- **D-pad, home button, left/right joysticks, and L4/R4** buttons are not supported.
- The turbo settings will not be saved permanently and will revert to default settings after the controller is powered off or disconnected.

Turbo Mode

Turn on: Hold the button you would like to assign the turbo functionality, then press the **Star button** to enable the Turbo Mode, and the **mapping indicator** will blink rapidly.
Turn off: Hold the button you would like to deactivate the turbo functionality, then press the **Star button** to disable the Turbo Mode, and the **mapping indicator** will turn off.

Auto Turbo Mode

Turn on: Hold the button you would like to assign the turbo functionality, then press the **Star button** twice to enable the Turbo Mode, and the **mapping indicator** will blink rapidly.
Turn off: Hold the button you would like to deactivate the turbo functionality, then press the **Star button** to disable the Turbo Mode, and the **mapping indicator** will turn off.

L4/R4 Configuration

- One button or multiple buttons on the controller can be remapped to the L4 / R4 button.
- Configuration on the **left/right joysticks** are not supported.
- The **mapping indicator** will blink continuously when the configured button is pressed.
- Hold the **L4 / R4 button** + the button you would like to configure, then press the **Mapping button** to complete the configuration. Repeat the same procedure to cancel the configuration.

Battery

- 15 hours of playtime with a 480mAh built-in battery pack, rechargeable with 1 to 2 hours charging time.

status —	**LED indicator —**
Low battery mode →	Red LED blinks
Battery charging →	Red LED stays solid
Battery fully charged →	Red LED turns off

- The controller will automatically shut down if it fails to connect within 1 minute of startup, or if there are no operations within 15 minutes after establishing a connection.
- The controller will not shut down during wired connection.

Safety Warnings

- Please always use batteries, chargers, and accessories provided by the manufacturer.
- The manufacturer is not liable for any safety issues arising from the use of non-manufacturer-approved accessories.
- Do not attempt to disassemble, modify, or repair the device yourself. Unauthorized actions may result in serious injury.
- Avoid crushing, disassembling, puncturing, or attempting to modify the device or its battery, as these actions can be dangerous.
- Any unauthorized changes or modifications to the device will void the manufacturer's warranty.

Support

- Please visit support.8bitdo.com for further information & additional support.